

# INSTRUCTION MANUAL AND USE

## ALULED SERIES

Note: Before start managing the projector read the whole manual carefully.  
Before start manipulating the luminaire, make sure electric current is off.  
Luminaires must be manipulated by qualified professional staff.

### Assembly and electric connection

1. Secure the luminaire to the working area firmly, making sure of its firm fastening.
2. Open the gear box to access to the electrical gear. (Fig. 1)
3. Introduce power cable through the cable-entry placed on head top.
4. Peel the wire and connect the end to the connection points N, L and Ground. (Fig. 2)
5. Close the gear box. (Fig. 3)

Fig. 1




Fig. 2





Fig. 3




### Dimensions


ALULED-M-IP65-360-90°



ALULED-L-IP65-460-90°



ALULED-XL-IP65-560-90°



Weight: from 3,5Kg. to 12,2Kg.  
(see catalogue)